

CORNER POST CAP REMOVAL

To remove the corner post caps you must remove the bottom caps and wind deflectors.

The bottom caps are on the very bottom of the corner post held on by two (2) self-tapping screws. A 5/16 nut driver will remove these screws.

The wind deflectors are located at the upper front corners of the front door openings. These are held on by three (3) 3/16" or #11 rivets. Drill the rivets out to remove the wind deflector.

Looking up at the bottom of the corner post cap you will see a hole or slot that you can put a flathead screwdriver in to remove the corner post cap cover strip. Once you remove the cover strip, the screws holding the corner post cover will be revealed. Remove these screws and the cap will come off. You might have to cut loose the grey silicone that seals the top of the cap.

Removing the corner post cap will reveal some of the wiring.

To reinstall, follow the procedure in reverse.