

omnivan® ROLL-UP DOOR MAINTENANCE PROCEDURES

The following items should be performed periodically to assure proper mobility of shutter curtain and all working mechanisms:

1. Check travel of shutter curtain for proper side clearance in guides. The shutter curtain should have space between the back wall of the guide and the curtain's end clips.
2. As shutter is traveling onto the roller drum, inspect each slat for damage including missing end clips.
3. Mounting brackets, motor mounts, guide bolts and any other fasteners should be checked and tightened if necessary.
4. With the curtain in the open position, wipe inside of guides clean and lubricate with lubricants that do not collect dust or other particles. Use substances such as graphite or silicon spray.